

**USB2.0**  
**JetFlash™**

# **User's Manual**

(Version 1.4)

***Transcend***  
***Exceeding Your Expectations***

# Table of Contents

|                                                                                   |          |
|-----------------------------------------------------------------------------------|----------|
| <b>Introduction .....</b>                                                         | <b>2</b> |
| Package Contents .....                                                            | 2        |
| Features .....                                                                    | 2        |
| System Requirements .....                                                         | 2        |
| <b>Driver Installation .....</b>                                                  | <b>3</b> |
| Driver Installation for Windows® 98SE .....                                       | 3        |
| Driver Installation for Windows® Me, 2000 and XP .....                            | 3        |
| Driver Installation for Mac™ OS 9.0, or Later .....                               | 3        |
| Driver Installation for Linux™ Kernel 2.4.2, or Later .....                       | 3        |
| <b>Formatting the JetFlash™ .....</b>                                             | <b>4</b> |
| <b>Safely Remove the JetFlash™ from a Computer .....</b>                          | <b>5</b> |
| Remove the JetFlash™ in Windows® 98SE .....                                       | 5        |
| Remove the JetFlash™ in Windows® Me, 2000 and XP .....                            | 5        |
| Remove the JetFlash™ in Mac™ OS, or Later and Linux™ Kernel 2.4.2, or Later ..... | 5        |
| <b>JetFlash™ 150 Series .....</b>                                                 | <b>6</b> |
| Specifications .....                                                              | 6        |
| Ordering Information .....                                                        | 6        |
| <b>JetFlash™ 120 Series .....</b>                                                 | <b>7</b> |
| Specifications .....                                                              | 7        |
| Ordering Information .....                                                        | 7        |
| <b>JetFlash™ 110 Series .....</b>                                                 | <b>8</b> |
| Specifications .....                                                              | 8        |
| Ordering Information .....                                                        | 8        |
| <b>JetFlash™ 2A Series .....</b>                                                  | <b>9</b> |
| Specifications .....                                                              | 9        |
| Ordering Information .....                                                        | 9        |

# Introduction

Congratulations on purchasing Transcend's **JetFlash™**. This tiny device allows you to exchange huge amounts of data and information between it and any desktop or notebook computer with a USB port. The **JetFlash™** plugs directly into your desktop or notebook computer, has a large storage capacity and much faster data transfer rates, making it perfect for storing and transferring your files, folders, documents, photos and other personal digital content. In addition, the **JetFlash™**'s small convenient size, superior data retention and impressive appearance will provide you with a brand-new data storage experience.

## Package Contents

The **JetFlash™** package includes the following items:

- **JetFlash™**
- Neck Strap
- Utility CD
- USB Extension Cable (JetFlash™ 2A only)
- Quick Instruction Guide

## Features

- Hi-Speed USB 2.0 compliant and USB 1.1 backwards compatible
- Easy Plug and Play installation
- Driverless (Only Windows® 98SE needs the enclosed driver)
- Powered via the USB port. No external power or battery needed
- Additional bundled software (helps you manage your data)
- LED indicates the usage status of the **JetFlash™**

## System Requirements

Desktop or notebook computer with a USB port and one of following operating systems:

- Windows® 98SE
- Windows® Me
- Windows® 2000
- Windows® XP
- Mac™ OS 9.0, or later
- Linux™ Kernel 2.4.2, or later

# Driver Installation

## Driver Installation for Windows® 98SE

Put the Driver CD into the CD-ROM (Auto-Run supported). Click the **Win98 Driver** button.



## Driver Installation for Windows® Me, 2000 and XP

No drivers are required. These Windows operating systems have built-in drivers to support the **JetFlash™**. Simply plug the **JetFlash™** into an available USB port and Windows will install the files needed to use your device. A new **Removable Disk** drive with a newly assigned drive letter will appear in the **My Computer** window.

## Driver Installation for Mac™ OS 9.0, or Later

No drivers are required. Just plug the **JetFlash™** into an available USB port and your computer will automatically detect it.

## Driver Installation for Linux™ Kernel 2.4.2, or Later

No drivers are required. Just plug the **JetFlash™** into the USB port and mount it.

- Example:
1. First create a directory for the **JetFlash™**  
`mkdir /mnt/jetflash`
  2. Mount the **JetFlash™**  
`mount -a -t msdos /dev/sda1 /mnt/jetflash`



# Formatting the JetFlash™

1. Plug the **JetFlash™** into a USB port and right-click on the removable disk.
2. Select **“Format”** in the drop down menu to format the **JetFlash™**.



**WARNING! Formatting the Disk will erase all of the data on your JetFlash™**

3. Click on the **“Start”** button to begin formatting the **JetFlash™** and follow the on-screen instructions.



# Safely Remove the JetFlash™ from a Computer

## Remove the JetFlash™ in Windows® 98SE

Disconnect the **JetFlash™** from your system directly when data is not transferring.

## Remove the JetFlash™ in Windows® Me, 2000 and XP

1. Select the  icon on the system tray.
2. The “**Safely Remove Hardware**” pop-up menu will appear. Select it to continue.



3. A message box will appear stating: “**The ‘USB Mass Storage Device’ device can now be safely removed from the system.**”



## Remove the JetFlash™ in Mac™ OS, or Later and Linux™ Kernel 2.4.2, or Later

Drag and drop the Disk icon corresponding to your **JetFlash™** into the trashcan. Then unplug your **JetFlash™** from the USB port.

# JetFlash™ 150 Series

## Specifications

|                 |                    |
|-----------------|--------------------|
| ● Size:         | 59mm x 19mm x 10mm |
| ● Weight:       | 10 g               |
| ● Certificates: | CE, FCC, BSMI      |

## Ordering Information

| Transcend P/N | Memory Size | Color  |
|---------------|-------------|--------|
| TS256MJF150   | 256MB       | Green  |
| TS512MJF150   | 512MB       | Blue   |
| TS1GJF150     | 1GB         | Red    |
| TS2GJF150     | 2GB         | Silver |



# JetFlash™ 120 Series

## Specifications

|                 |                    |
|-----------------|--------------------|
| ● Size:         | 75mm x 25mm x 11mm |
| ● Weight:       | 15 g               |
| ● Certificates: | CE, FCC, BSMI      |

## Ordering Information

| Transcend P/N | Memory Size | Color      |
|---------------|-------------|------------|
| TS128MJF120   | 128MB       | Amber      |
| TS256MJF120   | 256MB       | Orange     |
| TS512MJF120   | 512MB       | Red        |
| TS1GJF120     | 1GB         | Blue       |
| TS2GJF120     | 2GB         | Light Blue |
| TS4GJF120     | 4GB         | Turquoise  |





# JetFlash™ 110 Series

## Specifications

|                 |                    |
|-----------------|--------------------|
| ● Size:         | 64mm x 21mm x 10mm |
| ● Weight:       | 11 g               |
| ● Certificates: | CE, FCC, BSMI      |

## Ordering Information

| Transcend P/N | Memory Size | Color |
|---------------|-------------|-------|
| TS128MJF110   | 128MB       | Gold  |
| TS256MJF110   | 256MB       | Green |
| TS512MJF110   | 512MB       | Blue  |
| TS1GJF110     | 1GB         | Red   |
| TS2GJF110     | 2GB         | Gray  |
| TS4GJF110     | 4GB         | Amber |



# JetFlash™ 2A Series

## Specifications

|                 |                                  |
|-----------------|----------------------------------|
| ● Size:         | 75mm x 25mm x 11mm (Mini Size)   |
|                 | 88mm x 33mm x 15mm (Normal Size) |
| ● Weight:       | 15 g (Mini Size)                 |
|                 | 24 g (Normal Size)               |
| ● Certificates: | CE, FCC, BSMI                    |

## Ordering Information

| Transcend P/N | Memory Size | Color               |
|---------------|-------------|---------------------|
| TS128MJF2A    | 128MB       | Silver, Mini Size   |
| TS256MJF2A    | 256MB       | Silver, Mini Size   |
| TS512MJF2A    | 512MB       | Silver, Mini Size   |
| TS1GJF2A      | 1GB         | Silver, Mini Size   |
| TS2GJF2A      | 2GB         | Silver, Mini Size   |
| TS4GJF2A      | 4GB         | Silver, Mini Size   |
| TS8GJF2A      | 8GB         | Silver, Normal Size |



# JetFlash™ V20 Series

## Specifications

|                 |                    |
|-----------------|--------------------|
| ● Size:         | 75mm x 25mm x 11mm |
| ● Weight:       | 15 g               |
| ● Certificates: | CE, FCC, BSMI      |

## Ordering Information

| Transcend P/N | Memory Size | Color  |
|---------------|-------------|--------|
| TS512MJFV20   | 512MB       | Orange |
| TS1GJFV20     | 1GB         | Blue   |
| TS2GJFV20     | 2GB         | Red    |
| TS4GJFV20     | 4GB         | Green  |



# JetFlash™ V30 Series

## Specifications

|                 |                   |
|-----------------|-------------------|
| ● Size:         | 60mm x 16mm x 7mm |
| ● Weight:       | 7 g               |
| ● Certificates: | CE, FCC, BSMI     |

## Ordering Information

| Transcend P/N | Memory Size | Color  |
|---------------|-------------|--------|
| TS512MJFV30   | 512MB       | Orange |
| TS1GJFV30     | 1GB         | Blue   |
| TS2GJFV30     | 2GB         | Red    |

